

LSPR sensor modified by molecularly imprinted sol-gel for selective organic acid vapor detection


Liang Shang, Chuanjun Liu, Kenshi Hayashi*

Graduate School of Information Science and Electrical Engineering,
Kyushu University, Fukuoka, Japan



Introduction

Body odor



Volatile organic compounds (VOCs)

Fatty acids

Alcohols

Aldehydes

Esters

Ketones

Amines

Application



Medical diagnosis



Physiological condition





Forensic



Body odor fingerprint

Introduction

Localized surface plasmon resonance (LSPR)



Transmittance measurement using LSPR of MNPs.
cf.) B. Chen, M. Ota, K. Hayashi: IEEJ Trans. SM, 133E, 90, 2013

Absorption spectra

Particle size, shape and composition

Surrounding media

Merit & drawback


Fast response/recovery speed

Non specificity

Introduction


Molecularly Imprinted Sol-gel (MISG)

Reaction principle





Imprinting method

Covalent bonding



Hydrogen bonding



(Adv. Mater. 2001,13,1327-1330)
(Anal. Bioanal. Chem. 2011, 400, 2457-2462)

Compared with other MIP

**Stability of
chemical and thermal**

Concept

MISG-LSPR sensor array

MISG layer


Selective adsorption layer

AuNPs layer


LSPR sensing layer

Detecting the change of
transmittance light

The target fatty acid vapor
would be selective detected.



Gas mixture





Experiment

MISG material

Iso-propanol 2 mL

Ti(OBu)₄ 136 μL

APTES 24 μL

Template 50 μL


TiCl₄ 25 μL

70 °C water bath, 1h


MISG-AuNPs film fabrication

Step 1 APTES modification

(3-Aminopropyl) triethoxysilane



APTES ethanol solution
(v:v = 1:10), 8 h



Step 2 Sputtered AuNPs and anneal

Sputtering AuNPs thickness: 3nm

Anneal: 200 °C, 5h, air




Step 3 MISG reaction solution spin coating

MISG solution: 20 μL

Spin coating speed:

1000/3000/5000 rpm




Template molecules

Titanate sol-gel matrix




Step 4 Annealed for removing templates

Anneal: 200 °C, 1h, air




Experiment

Testing system



Gas generate system



Transmittance spectra testing system

$$k = \frac{22.4 \times (273 + t) \times 760}{M \times 273 \times P}$$


t – Thermodynamic temperature (°C)
M – Molecular weight (g/mol)
P – Atmosphere (mmHg)

$$C = \frac{k \times D_r \times 10^3}{F}$$


Dr – Diffusion rate (μg/min)
F – Flow rate of dilute gas (ml/min)

Results and discussion


■ Transmittance spectra of MISG-LSPR sensors.



Spectra parameters




SEM image



The changes of transmittance spectra are affected by their different surface features.


Results and discussion

Real-time response of HA-MISG and NISG with different coating speeds to HA vapors (Transmittance at λ_{\min})



Results and discussion

■ Real-time response of HA-MISG-LSPR sensor to three fatty acid vapors (PA/HA/OA)



HA-MISG-LSPR sensor

Template molecule: HA

Spin coating speed: 3000 rpm

PA: Propanoic acid (40.93 ppm)

HA: Hexanoic acid (21.05 ppm)


OA: Octanoic acid (11.23 ppm)

$$K = \text{Normalized } T/C_{gas}$$

A specific selectivity to HA vapors was obtained


Results and discussion

■ MISG-LSPR sensor array for fatty acid vapors discrimination.



Fatty acid vapors


Propanoic acid (PA) Hexanoic acid (HA)
 Heptanoic acid (HPA) Octanoic acid (OA)
 Propanoic acid + Hexanoic acid (PA+HA, v:v = 1:1)
 Propanoic acid + Octanoic acid (PA+OA, v:v = 1:1)
 Hexanoic acid + Octanoic acid (HA+OA, v:v = 1:1)



Typical response of HA-MISG sensor to fatty acid vapors.

Results and discussion

■ PCA and linear discriminant analysis (LDA) results for diverse fatty acid vapors



- PC1-PC2 space, all the samples were clustered in their groups.
- PC1-PC3 and PC2-PC3 space, an overlapped was observed.
- In LDA space, an acceptable discriminated results was observed.
- MISG-LSPR sensor array would be applied in fatty acid vapors discrimination.

Conclusion

- An **AuNPs** film combined with **MISG** was utilized for the determination of **fatty acid** vapors **selectively**.
- The **adsorption capacity** of pure titanate sol-gel matrix is **weak**.
- By controlling the **spin coating speed**, the **adsorption ability** of MISG would be controlled.
- Based on the **MISG-LSPR sensor array**, fatty acid vapors would be **detected** and **discriminated**.

Thank you for your attention

